

NF1447Ws-2

MINI SCRAPER W/2 DOUBLE-EDGED PLASTIC BLADES





Push lock tab open through entire blade

Blades storage



Carefully slide blade sideways out of holder



NF1447W-

NF1447Vs-2

PLASTIC CLEAN SCRAPER W/2 DOUBLE-EDGED PLASTIC BLADES

NF1447Rs-5

PLASTIC CLEAN SCRAPER W/5 DOUBLE-EDGED PLASTIC BLADES

NF1447U

PLASTIC CLEAN SCRAPER











NF5101C

NF5101H



NF1621Cs-3

PLASTIC CLEAN SCRAPER W/3 DOUBLE-EDGED PLASTIC BLADES









Blades storage in handle

Push down

Changing blade

Push up



PLASTIC CLEAN SCRAPER






Unscrew the screw

Changing blade





Tighten the screw Close the cap if not using



PLASTIC CLEAN SCRAPER



Hold the scraper and push forward in the direction of OPEN to expose the blade



Glide the blade of 30 degrees



Wipe it clean after gently and evenly using it .Be sure to across the cooktop cover the blade by surface at an angle sliding the top back over the protective lip as indication of CLOSE



NF1610C

PLASTIC CLEAN SCRAPER

Cleaning glass ceramic hobs: use on the hob when cold after first wetting it with a cloth








Protection





Use. Caution: Contains blade

Replacing blade







NF1443Q

STAINLESS STEEL CLEAN SCRAPER





Changing blade







NF1630C

CLEAN SCRAPER W/PLASTIC **HANDLE**







Unscrew the screw

Changing blade Tighten the screw



Quick change blade holder firmly holds a single edge razor blade

NFNF1631E





Press adjusting button to stretch or shorten



NF5050C

RESIN CLEAN SCRAPER

Clean all smooth surfaces







Glass Top Stove

e Tile Flooring

BBQ Net





Cookware

Ice and snow

Material conforms to the composition requirments for incidental food contact use



METAL FOLD-UP CLEAN SCRAPER





Great for removing :bumper stickers, decal,paint specs ,label,etc





The blade arm pivots into the handle for safe and convenient storage

Quick change blade holder firmly holds a single edge razor blade

NF1901C

METAL FOLD-UP CLEAN SCRAPER






Great for removing :bumer stickers, decal,paint specs ,label,etc



The blade arm pivots into the handle for safe and convenient storage



Quick change blade holder firmly holds a single edge razor blade





NF1452K

NF1452Kc

NF1452Ka



SOFT

Best for:

Auto paint
Other plastics
Finished wood
Painted surfaces
Soft surfaces



MEDIUM

Best for:

Fiberglass & gelcoat Gaskets Soft metals Bathtubs & tile Uneven surfaces



HARD

Best for:

Windows
Granite & marble
Metals
Unfinished wood
Ridfid surfaces

Clean scraper with/5 plastic blades Packing:Plastic Bag



100pcs plastic blades Packing:Paper Box



25pcs plastic blades Packing:Plastic Bag





200pcs plastic blades Packing: Plastic bucket





NF1623H

GLASS SCRAPER

Retractable blade guard Push button blade change 4 inch wide blade Use easy,natural sideways motion



press and pull back using both thumbs



press and push forward with thumb



push rear button to release blade



change blade





CLEANING SCRAPER



Press button to release blade



Change other fitting part



Plastic blade for cleaning acrylic or delicate glass to remove general algae



Rust resistant stainless steel blade for calcified deposits on glass aquariums



A fabric pad covered blade for fine cleaning and mopping



NF0500C

CERAMIC SCRAPER

Made of advanced ceramic Close in hardness to diamond Non-corrosive blade





flat edge



Blade can be folded



